


CONNECT THESE TWO PINS TOGETHER WITH  
A JUMPER FOR THE MAXIMUM COUNT SHOWN.

MAX COUNT = 32 WITH NO JUMPER

MAX COUNT = 16

MAX COUNT = 8

MAX COUNT = 4



404436  
DIGITAL MEMORY SELECT ASSEMBLY  
INSTRUCTION SHEET #190328